E-Z Connect® Premium Landscape Edging

Installation Guidelines

Using a straight edge spade, make a trench along the bed area where edging is to be installed. Trench should be approximately 3.5" deep, depending on desired finished edging height.

Slide connectors into track system with locking pegs facing toward pre-drilled holes on each edging piece. Locking pegs should click into pre-drilled holes on each of the edging pieces, providing a clean, locked joint without overlapping.

Place edging in the trench with the track groove toward the planting bed. Note that installers may find it easier to connect all pieces before placing edging in trench.

Push anchoring hooks vertically, through pre-drilled holes in track system and into ground. For best results, place hooks evenly throughout installation.

In tougher soil conditions, installers may need to use a hammer or rubber mallet to gently pound the anchoring hooks to secure edging at proper depth.

Tightly pack soil around edging and install landscape fabric and ground cover (decorative stone, mulch, etc.) to the top of the edging.